

MOC FUEL ADAPTERS (Master Kit 73035)

7/13/10



72001
FORD 3/8 Supply



72002
FORD 1/2 Supply



72003
12 mm Banjo



72004
8 mm Cold start



72005
12 mm Cold start TBI



72006
1/4 X 5/16 barb TBI



72007
7/16-20 X 5/16 barb



72008
5/16 open supply



72009
5/16 Plug



72010
GM cold start TBI



72011
3/8 GM TBI



72012
10 mm cold start



72013
12 mm L- Jetronic



72014
14 mm L- Jetronic



72017
16 mm Mitsubishi



72018
12 mm Banjo Bolt



72019
GM 90 Degree Schrader



72021
1/4 Ford Return Plug



72022
GM Return Plug



72023
5/16 Return Plug



72024
3/8 Q.D. Return Plug



72025
1/2 Q.D. Return Plug



72026
12 mm Return Plug



72027
14 mm Return Plug



72028
8 mm Return Plug



72029
12 mm Cap Nut



72031
G. M. TBI 3/8



72034
1/4 Duckbill QD



72035
5/16 X 1/4 Return Loop



72036
14 MM X 5/16 Barb



72037

3/8 Ford Disconnect Tool



72038

1/2 Ford Disconnect Tool



72039

5/16 G.M. Release



72040

3/8 G.M. Release



72041

Clamp Small



72048

5/16 BMW



72050

5/16 X 5/16 Barb Loop



72051

3/8 Supply



72054

12 mm Double Banjo



72055

12 mm Copper Washer



72057

Toyota Tacoma Truck
14 mm X 1.5



72058

12 mm X 14 mm Banjo



72099

Ford Schrader Q.D.



72100

12mm Cold Start Toyota



72101

5/16 Quick Disconnect



72102

3/8 Quick Disconnect



72103

Maxima 2000-up Male



72106

Ford Focus 2003-UP



74466

45 Degree Schrader



72501

12 mm Banjo long hose



73031

1/4 Male Quick Disc



74275

3/8 Female Q.D.



74276

5/16 Female QD



73033

19 mm Mitsubishi



74234

Maxima 2000-up Female



74239

3/8 Threaded TBI



72107

GM Schrader Straight.



72108

Cap, Fuel 7/16



94054

Pinch Pliers



73037 & 73038

Volvo 3.2 Schrader



73040
14mm X 1.5mm
Lexus / Toyota
Land Rover



73041
16mm X 1.5 m
90 degree male
Porsche



73039
90 degree QD
5/16 Female



74480
Replacement parts
for 72099 (5ea)

Acura / Honda			Chrysler, Kit	Sprinter	
73000	Acura / Honda Kit		73005	Chrysler, Dodge Plym	
72003	12mm Hose, Banjo		72003	12mm Banjo Threaded	
72023	5/16" Return Plug		72007	7/16-20 X5/16 BARB	
72029	12 mm Cap Nut		72008	5/16" Supply Adapter	
72034	1/4 Duckbill Adapter QD		72010	GM Cold Start Adapter	
72041	Hose Clamp		72017	16mm Mitsubishi Adapter	
72054	Bolt, 12mm Dale Banjo		72018	12mm Banjo Bolt	
72055	Washer, 12mm Copper		72019	90Degree Schrader GM	
72058	12mm X14mm Banjo		72023	5/16" Return Plug	
72101	Adaptor 5/16 Male QD		72026	12mm Return Plug	
72102	Adaptor 3/8 Male QD		72034	1/4 Duckbill QD Female	
72106	Ford Focus 2003		72035	5/16" x 1/4" Barb Loop	
72108	Cap, Fuel/Gasket 7/16-20		72101	5/16 Quick Disconnect	
72501	Long Hose w/Banjo		72102	Adaptor 3/8 Male QD	
73031	1/4 male Quick Dis.		72103	10mm Mitsubishi Adapter	
74275	Adaptor Female 3/8 QD		72107	Adaptor GM Schrader	
74276	Adaptor Female 5/16 QD		73031	1/4 Male Quick Dis.	
73039	90 degree 5/16 QD Female		74275	Adaptor Female 3/8 QD	
			74276	Adaptor Female 5/16 QD	
			73039	90 deg 5/16 QD Female	
Alfa Romeo					
73002	Alfa Romero				
72008	5/16" Supply Adapter		Daihatsu		
			73006	Daihatsu Kit	
Audi			72004	8mm Cold Start Adapter	
73003	Audi Kit		72012	10mm Cold Start Adapter	
72003	12mm Hose, Banjo		72023	5/16" Return Plug	
72005	12mm Cold Start Adapter				
72014*	14mm L-Jetronic Threaded				
72018	12mm Banjo Bolt		Fiat		
72026	12mm Return Plug		73007	Fiat Kit	
72027	14mm Return Plug		72008	5/16" Supply Adapter	
			72023	5/16" Return Plug	
BMW					
73004	BMW Kit				
72005	12mm Cold Start Adapter				
72008	5/16" Supply Adapter				
72026	12mm Return Plug				
72099	Adapter Portrait, Ford Q D				
72048	Adaptor 5/16 BMW				
72101	5/16 Quick Disconnect				
72041	Hose Clamp Small				
74276	Adaptor Female 5/16 QD				
72013	Adapter 12mm L-Jetronic				
73039	90 deg. 5/16 QD Female				
72108	Cap ,Fuel 7/16 /Washer				
72019	90 deg Schrader GM				

Ford			Geo	
73008	Ford, Lincoln Mercury,		73009	Geo Kit
72001	3/8" Quick Supply		72004	8mm Cold Start Adapter
72002	1/2" Quick Supply		72008	5/16" open supply
72008	5/16" Supply Adapter		72012	10mm Cold Start Adapter
72021	Ford Return Plug		72051	3/8" Supply Adapter
72023	5/16" Return Plug			
72024	3/8" Quick Return			
72025	1/2" Quick Return		Hyundai	
72034	1/4" Duckbill Adapter		73011	Hyundai Kit
72037	3/8" Ford Disconnect		72003	12mm Banjo Threaded
72038	1/2" Ford Disconnect		72017	16mm Mitsubishi Adapter
72041	Hose Clamp Small		72103	10mm Mitsubishi male
72099	Adapter Portrait, Ford QD			
72106	Ford Focus 2003		Isuzu	
72108	Cap, Fuel / Gasket 7/16		73012	Isuzu Kit
74275	Adaptor Female 3/8 QD		72008	5/16" Supply Adapter
74276	Adaptor Female 5/16 QD		72023	5/16" Return Plug
72101	5/16 Quick Disconnect			
72102	Adaptor 3/8 Male QD			
73031	1/4 Male Quick Dis.		Jaguar	
73039	90 deg. 5/16 QD Female		73013	Jaguar Kit
			72008	5/16" Supply Adapter
			72014	14mm L-Jetronic Threaded
			72023	5/16" Return Plug
			72027	14mm Return Plug
General Motors			72019	90 Degree Adapter
73010	General Motors Kit		72107	Adaptor GM Schrader
72005	12mm Cold Start Adapter		72099	Adapter Portrait, Ford QD
72008	5/16" Supply Adapter			
72009	5/16" Inverted Plug			
72010	GM Cold Start Adapters			
72011	GM TBI Adapter		Jeep,	
72021	Ford Return Plug		73014	Jeep, Eagle, Renault
72022	GM Return Plug		72006	AMC TBI Adapter
72023	5/16" Return Plug		72008	5/16" Supply Adapter
72031	GM TBI Special Adapter		72009	5/16" Inverted Plug
72039	5/16" GM Release Tool		72022	GM Return Plug
72040	3/8" GM Release Tool		72023	5/16" Return Plug
72041	Hose Clamp Small		72041	Hose Clamp Small
72102	3/8 Male Quick Disc		72107	Adaptor GM Schrader
72107	Adaptor GM Schrader		74466	45 Degree Schrader
74239	Adapter at Filter 3/8 TBI			
74275	Fuel, Female 3/8 QD		Kia	
72101	5/16 Quick Disconnect		73034	KIA KIT
74276	Adaptor Female 5/16 QD		72099	Schrader quick dis.
73039	90 deg. 5/16 QD Female		72023	5/15 return plug
			72101	5/16 Quick Disconnect
			74276	Adaptor Female 5/16 QD
			73039	Adapter Female 5/16 90deg

Land Rover			Nissan	
73043	Land Rover Kit		73018	Nissan Kit
72019	90Degree Schrader GM		72008	5/16" Supply Adapter
72057	Toyota/Tacoma Truck		72023	5/16" Return Plug
72107	Adaptor GM Schrader		72035	5/16" x 1/4" Barb Loop
74275	Adaptor Female 3/8 QD		72041	Hose Clamp
74276	Adaptor Female 5/16 QD		72050	5/16" x 5/16" Barb
73040	2.7Toyota / 4.0L Lexus / 4.3L Land Rover		72103	Maxima (2000 -up) male
			74234	Maxima 2003 female
Mazda			72101	5/16 Quick Disconnect
Mazda			74276	Adaptor Female 5/16 QD
73015	Mazda Kit		73039	5/16 90 Degree QD
72008	5/16" Supply Adapter			
72023	5/16" Return Plug		Peugeot	
72035	5/16" x 1/4" Barb Loop		73019	Peugeot Kit
72099	Portrait, Ford Q D		72003	12mm Banjo Threaded
72041	Hose Clamp Small			
			Porsche	
			73020	Porsche Kit
Mini Cooper			72003	12mm Banjo Threaded
73042	Mini Cooper Kit		72008	5/16" Supply Adapter
72019	90Degree Schrader GM		72013	12mm L-Jetronic Threaded
72099	Portrait, Ford Q D		72026	12mm Return Plug
72107	Adaptor GM Schrader		72035	5/16" x 1/4" Barb Loop
			72041	Hose Clamp Small
			73041	90deg. 16mm X 1.5 Male
Mercedes				
73016	Mercedes Kit		Saab	
72005	12mm Cold Start Adapter		73021	Saab Kit
72014	14mm L-Jetronic		72003	12mm Banjo Threaded
72026	12mm Return Plug		72026	12mm Return Plug
72107	Adaptor GM Schrader			
74466	45 Degree Schrader		Saturn	
			73022	Saturn Kit
			72008	5/16" Supply Adapter
Mitsubishi			72009	5/16" Inverted Plug
73017	Mitsubishi Kit		72011	GM TBI Adapter-Early
72017	15mm Mitsubishi Adapter		72022	GM Return Plug
72019	90 Degree Adapter		72023	5/16" Return Plug
72103	10mm Mitsubishi male		72031	GM TBI Special Adapter
73033	19 MM Mitsubishi Male		72039	5/16" GM Release Tool
74234	Maxima 2000 -up Female		72040	3/8" GM Release Tool
			72041	Hose Clamp Small
			72107	Adaptor GM Schrader
			74466	Adapter 45 deg. Schrader

DIESEL

INJECTOR

ADAPTERS

Kit # 72271



72246
5/16" Male
(2 Each)



72249
3/8" Female Q.D.
(2 Each)



72235
12mm 90 Deg. Banjo
(2 Each)



72248
3/8" Male 90 Deg.
(2 Each)



72245
1/2" Female Q.D.
(2 Each)



72227
Tank to Tank Loop
(1 Each)



72251
1/2" Male
(2 Each)



72232
1/2" Open-Ended
(2 Each)



72239
Primer Adapter
(1 Each)



72247
5/16" Female Q.D.
(2 Each)



72236
12mm Banjo
(2 Each)